



An RH chair is the perfect work tool, a chair that puts you in optimal position all day, every day.

A few simple adjustments is all it takes to make your RH chair fit your individual anatomy. An RH chair supports upright posture and active sitting. Increasing your performance.

RH MERE0

Uncompromising ergonomics combined with innovation and design. RH Mereo helps you to achieve an active sitting position, better concentration and better performance. RH Mereo is also perfect for workplaces where several people use the same chair.

Ergonomics

Providing complete support in any working position, enabling you to always sit correctly and breathe properly.

- Sculptured seat with waterfall front combined tapered back with clear lumbar support and "Tvedt" cushion encourages movement and an upright posture.
- Uniquely smooth & frictionless movement, paired with intuitive weight adjustment.
- Anyone can adjust the chair to their own personal needs.
- Adjust your chair how you need it without being an ergonomic expert

Quality

- 10 year guarantee

Scandinavian Business Seating is certified in accordance to:

- ISO 9001
- ISO 14001

RH Mereo is certified in accordance to:

- EN 1335-1-2-3 A
- Möbelfakta
- NPR 1813
- ANSI/BIFMA

Environment

- Supports companies' environmental profile and credibility (CSR) - Cradle to cradle proof
- Easy to disassemble and no harmful chemicals
- ISO 14025 (EPD)
- GREENGUARD



Design

Materials and surfaces communicating comfort and wellbeing through bodyfitting forms. Expressing human performance.

Fire classifications

Foams and standard fabrics are tested to BS/EN 1021-1&2 (cigarette & match). Foam and fabric according to BS-5852 ignition source 5 (crib 5) can be delivered on request. Please contact our customer service for further information. RH Mereo can be delivered according to CAL TB-133

Maintenance

Vacuum clean the chair with a furniture brush or wipe it with a clean, cloth or sponge slightly dampened with lukewarm clean water.

Do not remove any plastic parts or attempt to open the seating mechanism. Contact your Scandinavian Business Seating dealer if the chair requires servicing or maintenance.

See www.rhchairs.co.uk for RH Mereo interactive user instruction guide.

RH MERE0	EN 1335	NPR 1813	ANSI/BIFMA	Möbelfakta	EPD, ISO 14025	GREENGUARD
✓	✓	✓	✓	✓	✓	✓





RH MERO 200 SILVER



RH MERO 200 BLACK



RH MERO 220 BLACK



RH MERO 220 SILVER

CHAIR MODELS AVAILABLE:

RH MERO

- 200 – Low back
- 220 – High back

MEASUREMENTS	RH MERO 200	RH MERO 220
Seat depth with seat slide	350-525	350-525 mm
Seat depth	466 mm	466 mm
Seat width	425 mm	425 mm
Seat height - standard gas stem	388-520 mm	388-520 mm
Seat angle adjustment	+7,7°-16°	+7,7°-16°
Height of lumbar support above the seat	160-235 mm	163-236 mm
Backrest height	478 mm	632 mm
Backrest height adjustment (from seat)	417-495 mm	570-648 mm
Backrest width	452 mm	474 mm
Back angle adjustment	19°	19°
Height of armrest above seat	183-297 mm	183-297 mm
Distance between armrests	309-510 mm	309-510 mm
Diameter of base	660 mm	660 mm

OPTIONS

- 1 Armrest 8T (height and width.), grey or black
- 2 Base 5T, polished aluminium
- 3 Base 5T, black black lacquered aluminium
- 4 Coat Hook Black
- 5 Coat Hook Silver

- 6 Coat Hanger, Black
- 7 Coat Hanger, Silver
- 8 Castors for hard floors
- 9 Neckrest

GAS STEMS

- 4T NPR silver or black approx. 410-550 mm
- B silver or black approx. 480-610 mm
- A silver or black approx. 495-620 mm

For other options see the RH Price List.

The design and specifications of RH Chairs' products are developed on an ongoing basis and the above formulations should not be perceived as completely final.