

# RH Mereo

## How to adjust your RH Mereo



Height of the chair

1



Seat depth

2



Backrest angle

3



Backrest height

4



Unlock the dynamic tilt

5



Tilt resistance

6



Height of armrest

7



Neckrest

8